

Installation Guide




Feather Flags - Blade - Ground Spike

2.5m (Small) - 3.1m (Medium) - 4.1m (Large) - 5.2m (X Large)

Feather Flag - Blade - Ground Spike

Feather Flag Dimensions


Profile View



Visible Height:
Small (2.5m)
Medium (3.1m)
Large (4.1m)
X Large (5.2m)

Ground Spike Base Dimensions

Profile View




Please note: Maximum wind speed 15-18mph.

Feather Flag - Blade - Ground Spike

Parts Checklist

- A 1 x Pole Kit Carry Bag (S, M, L or XL)
- B 1 1 x Pole Kit & Bungee (S)
- B 2 1 x Pole Kit & Bungee (M)
- B 3 1 x Pole Kit & Bungee (L)
- B 4 1 x Pole Kit & Bungee (XL)
- C 1 x Spike Base




Step 1

Insert spike base into soft ground until the spigot housing is flush with the ground, do not drive into the ground using the top of the spigot. It is vital only the driving pin is struck with the hammer.



Step 2

Assemble the pole in size order, large to small. This example shows assembly for the medium pole. Insert pole B into pole A and pole C into pole B.



Step 3

Thread the flag onto the pole ensuring that the pole is fully inserted into the strengthened end of the sleeve, take care not to damage the sleeve.



Feather Flag - Blade - Ground Spike

Step 4

Thread the bungee through the eyelet on the base of the flag. Create a loop and thread the rest of the bungee cord through. Attach the bungee cord to the plastic retaining collar and adjust the tension if necessary (to avoid rippling, do not over tension the flag)



Step 5

Place the assembled pole onto revolving spigot.

